




Sony Ericsson Xperia Pro MK16A Camera Replacement

Is your phone's camera not taking photos or videos properly? Use this guide to replace your camera.

Written By: Sean Gallagher



INTRODUCTION

This guide will help you replace the camera in your Sony Ericsson Xperia Pro MK16A phone. Follow along to install a new camera in about half an hour.



TOOLS:

- [iFixit Opening Tools](#) (1)
 - [T6 Torx Screwdriver](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Taking the Back Off



- Use a plastic opening tool to get the back cover off your phone.
- ✦ The plastic opener will work on any side, but be careful and pry gently.

Step 2 — Removing the Battery




- Locate the battery in your phone.
- Find the divot below the battery.
- Use your thumb to lift the battery out of the phone.

Step 3 — Remove Screws



- Remove the 4 black screws with the Phillips screwdriver.
- Remove the 4 silver screws with the Torx screwdriver.

Step 4 — Remove Back Case





- Insert the plastic opening tool in between the two halves of the case. Pry around the phone to detach the back case.

Step 5 — Access the Logic Board





- Remove the last screw that is connecting the logic board using the Phillips screwdriver.
- Undo the two ribbons.

Step 6 — Remove the Logic Board



- Undo that last connector.

Step 7 — Remove Camera



- Lift the camera off of its connector on the logic board.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 07:04:42 AM.